



ZEBRA
CAPTURE
YOUR EDGE

Introducing the Desktop Printer Battery and Carrying Case Accessories

Easily power and carry your Zebra ZD Series Desktop printer whether it's on a cart or on your side for on-the-spot printing

Battery Accessory

- **Field installable** – The battery accessory is designed for all models of the ZD410, ZD42X and ZD62X desktop printers. The battery pack fits into the accessory housing which mounts to the printer base. Four screws attach the housing to the printer.
- **Powerful** – The fully charged battery powers the printer for a full day of printing¹ at typical darkness and print speed. Supports all connectivity options including wireless radio.
- **Compatible with all printer configurations** – The battery will power a printer with wireless radio configuration, a cutter, peeler or Keyboard Display Unit (KDU) attached.
- **Flexible** – The battery is easily removed from the housing to be charged outside of the printer using the standard printer power supply.
- **Battery charge level indicator** – The indicator makes it easy to see when the battery charge level is getting low and needs to be charged.
- **Easy connection** – The battery connects to the existing power input jack. No additional wires or loose items to tangle or lose.
- **Compact design** – The battery accessory doesn't change the footprint of the printer.



¹Full day of printing is two rolls of media.

Carrying Case Accessory

- **Convenience** – The carrying case accessory provides you with another way to easily bring your desktop printer to the point of application whether it's in the middle of an agricultural field or a retail floor.
- **Availability** – For use with any of our ZD420/ZD421 and ZD620/ZD621 desktop printers- direct thermal or thermal transfer - and includes handles, an attachable shoulder strap and pouch for a TC5x mobile computer.
- **Simple to use** – Open access to easily change the media rolls or swap batteries without having to remove the printer.
- **Control and connections** – A clear window allows you to control the printer buttons while it's in the case and a latch to effortlessly plug in any cords.
- **Protection** – Padded sides and a rugged bottom to provide protection from minor bumps, plus an IP52 rating for protection against solid and liquid ingress.



NA and Corporate Headquarters
+1 800 423 0442
inquiry4@zebra.com

Asia-Pacific Headquarters
+65 6858 0722
contact.apac@zebra.com

EMEA Headquarters
zebra.com/locations
contact.emea@zebra.com

Latin America Headquarters
+1 786 245 3934
la.contactme@zebra.com